


Wire Connection Instruction



- Tips:
- 1, The cables above which are marked with ● are basic wires, should be well connected so as to power on the controller
 - 2, Hall angle test is prior to any further operations.
 (It may break the circuit inside the controller if one twists the throttle too rush before the hall angle is matched)